

Engine

Number	160
Oil	85, 102
Oil Filter	104
Overheats	129
Starting	56
Stop Switch	50, 53, 56, 151
Stopping	151
Will Not Start	128

Environment	158
--------------------------	-----

Equipment

Owner's Manual	71
Tool Kit	71

F

Flooded Engine	56
-----------------------------	----

Fuel

Recommended	68
Tank Capacity	68

Fuses	84, 146
--------------------	---------

G

Gasohol	166
----------------------	-----

Gasoline	67
-----------------------	----

H

Hazard Switch	50, 52
----------------------------	--------

Headlight Aim	125
----------------------------	-----

Headlight Dimmer Switch	50, 52
--------------------------------------	--------

Helmet Holder	72
----------------------------	----

High Beam Indicator	48
----------------------------------	----

High Coolant Temperature

Indicator	47, 129
------------------------	---------

Honda Contacts	170
-----------------------------	-----

Horn Button	50, 53
--------------------------	--------

I

Ignition Cut-off System

Banking Sensor	152
----------------------	-----

Side Stand	114
------------------	-----

Ignition Key	150
---------------------------	-----

Ignition Switch	51, 53, 56, 151
------------------------------	-----------------

Indicators	47
-------------------------	----

Information Record	177
---------------------------------	-----

Instruments	22
--------------------------	----

Instruments, Controls, & Other

Features	151
-----------------------	-----