


Instruments (Continued)

Total/Fuel mileage display

The total/fuel mileage display shows the odometer, tripmeter, fuel mileage gauge, and other information.

Press the SEL button to change the display.



Only in reserve fuel mode*

* Reserve fuel mode: When the 1st (E) segment of the fuel gauge flashes, the reserve tripmeter display and reserve fuel consumption display can be selected.