Instruments (Continued)

Average fuel mileage A/B

Shows each average fuel mileage in conjunction with each tripmeter.

When each tripmeter is reset, each average fuel mileage will also reset.

u To reset the tripmeter: (P26)

When each tripmeter is reset: "----" is displayed.

When "---.-" is displayed except for the above-mentioned cases, go to your dealer for service.

Fuel consumption A/B

Shows each fuel consumption in conjunction with each tripmeter.

When each tripmeter is reset, each average fuel consumption will also reset.

u To reset the tripmeter: (P26)

Above 300 gal (L): "300.0" is displayed.

When "----" is displayed, go to your dealer for service.