

## Backlight brightness setting

The brightness of the display can be set to H (high) or L (low).

When the SET button is pressed, the following display appears and the brightness is set.

u The brightness of the display can be adjusted to H (high)/L (low) for each. ( P34)



## Tachometer color information

Depending on the selected mode, the information of the riding conditions shows by changing the tachometer segment color.



The tachometer color information modes:

### Base color mode

- User setting mode
- DCT mode
- Gear position mode
- Engine rev mode

**ECO mode**

**Shift up mode**

When the user setting mode or DCT mode in the base color mode is set, the ECO mode and/or shift up mode can be used at the same time.