

Starting the Engine *(Continued)*

When you stop the engine

- a To stop the engine, put the transmission in Neutral (N indicator comes on).
 - u If you turn the ignition switch to the OFF position when the motorcycle in gear, the engine will shut off with the clutch disengaged.
- b Turn the ignition switch off.
- c Pull the parking brake lever when you park the motorcycle. (P50)