

## Shifting Gears *(Continued)*

### Changing between Neutral and AT MODE/MT MODE

#### Changing from Neutral (N) to AT MODE

Press the D/S side of the N-D switch (a ). The D mode indicator comes on, "1" is shown in the gear position indicator and first gear is selected.

#### Changing from AT or MT MODE to Neutral

Press N on the N-D switch (b ).

### Changing between D mode and S mode while in AT MODE

Press the D/S side of the N-D switch. The S or D mode indicator comes on (c , d ).

### Changing between AT MODE and MT MODE

Press the A/M switch (e ). The S or D indicator goes out while MT MODE is selected (f ).

Gear position indicator

