

Washing Precautions

Follow these guidelines when washing:

- Do not use high-pressure washers:
 - u High-pressure water cleaners can damage moving parts and electrical parts, rendering them inoperable.
 - u Water in the air intake can be drawn into the throttle body and/or enter the air cleaner.
- Do not direct water at the muffler:
 - u Water in the muffler can prevent starting and causes rust in the muffler.
- Dry the brakes:
 - u Water adversely affects braking effectiveness. After washing, apply the brakes intermittently at low speed to help dry them.
- Do not direct water in the luggage box:
 - u Water in the luggage box can damage your documents and other belongings.
- Do not direct water at the air cleaner:
 - u Water in the air cleaner can prevent the engine from starting.

- Do not direct water near the headlight:
 - u Any condensation inside the headlight should dissipate after a few minutes of running the engine.
- Do not use waxes containing compounds on matte painted surface:
 - u Use a soft cloth or sponge, plenty of water, and a mild detergent to clean matte painted surfaces. Dry with a soft clean cloth.

Aluminum Components

Aluminum will corrode from contact with dirt, mud, or road salt. Clean aluminum parts regularly and follow these guidelines to avoid scratches:

- Do not use stiff brushes, steel wool, or cleaners containing abrasives.
- Avoid riding over or scraping against curbs.