

Fuel consumption A/B

Shows each fuel consumption in conjunction with each tripmeter.

When each tripmeter is reset, each average fuel consumption will also reset.

► **To reset the tripmeter:** ➡ P.29

Above 300 gal (L): "300.0" is displayed.

When "---.-" is displayed, go to your dealer for service.

Trip time

Shows the operating time since the engine was started.

The trip time return to 0:00 when the readout exceeds 23:59 (hours:minutes).

Today date

To set the today date: ➡ P.36