

Switches *(Continued)*

NC750XD

Torque Control switch

Torque Control level setting and
Torque Control on/off.  P.56

Shift up switch (+)

To shift up the gear.  P.68

Headlight dimmer

-  : High beam
-  : Low beam

Turn signal switch

 Pressing the switch turns the turn signal off.

Shift down switch (-)

To shift down the gear.  P.68

Horn button

 **Hazard switch**  P.50

