

Fuel gauge

Remaining fuel when only 1st (E) segment starts flashing: approximately 0.394 US gal (1.45 L)




If the fuel gauge indicator flashes in a repeat pattern or turns off: P.91

Odometer [TOTAL] & Tripmeter [TRIP] & Clock (12-hour display)

MODE switch selects the odometer, tripmeter and clock

- Odometer: Total distance ridden
- Tripmeter: Distance ridden since tripmeter was reset (press and hold MODE switch to reset to 0.0 miles (0.0 km)).

To set the clock: P.22



➡ Press the MODE switch