



- **4.** Remove the dust cover.
- 5. Unhook the pin and remove the bulb.
- 6. Install a new bulb and parts in the reverse order of removal.
 - ► Install the dust cover with its "△" mark facing up.

Do not touch the glass surface with your fingers. If you touch the bulb with your bare hands, clean it with a cloth moistened with isopropyl (rubbing) alcohol.