

Instruments & Controls

The items listed below are described in this section.

Operation Component Locations	13
Indicators & Displays	16
Neutral Indicator	17
Reverse Indicator	17
Electric Power Steering (EPS) Indicator	17
4WD Differential Lock Indicator	17
High Coolant Temperature Indicator	17
PGM-FI Malfunction Indicator Lamp (MIL)	17
Seat Belt Indicator	17
Low Oil Pressure Indicator	18
Multi-function Display	21
Speedometer	22
Tachometer	23
Fuel Gauge	24
Odometer Display	25
Maintenance Minder Indicator	30
Digital Clock	31
Gear Position Indicator	32
AT Indicator, MT Indicator / LOW Indicator (except for SXS1000M3)	33
SPORT Indicator (except for SXS1000M3)	33
Drive Mode Indicator	34
Driver Controls	35
Ignition Switch	35
Headlight Switch	36
Shift Select Lever	37
Drive Mode Select Lever	38
AT/MT Switch (except for SXS1000M3)	40
SPORT Switch (except for SXS1000M3)	41
Shift Paddles (except for SXS1000M3)	42
Steering Wheel Adjustment Lever (except for SXS1000M3)	43

(cont'd)