


Lubrication

(except for SXS1000M3)

Lubricate the steering wheel tilt pivots as shown in the following illustration. Remove the clips (page 131) and the lower cover.



Lubricate the brake pedal pivot and accelerator pedal pivot as shown in the following illustration.

brake pedal pivot

accelerator pedal pivot

