

# Index

---

engine,	
number .....	262
oil .....	148
pinging .....	145
starting .....	98
stopping .....	98
sub-transmission .....	161
won't start .....	236
environment .....	231

## F

final gear oil .....	165, 167
flat tire .....	243
frame .....	195
fuel,	
fill cap .....	146
oxygenated .....	276
recommendation .....	145
tank capacity .....	146
fuses .....	248

## G

gap, spark plug .....	185, 267
gasohol .....	276
gasoline .....	145
gear position indicator .....	36

## H

headlight switch .....	41
hill start assist (HSA) .....	50