

# Indicators & Displays

---

|                              |  |
|------------------------------|--|
| Multi-function display       | This display includes the following functions.   |
| Speedometer                  | Shows driving speed in miles or kilometers per hour (page 25).   |
| Tachometer                   | Shows the engine rpm (page 26).  |
| Fuel gauge                   | Shows approximate fuel supply available (page 27).   |
| Odometer display             | Shows the odometer, tripmeter, coolant temperature gauge, hour meter, maintenance tripmeter and maintenance hour meter (page 28).            |
| Maintenance minder indicator | Shows when specified maintenance interval is reached (page 33).  |
| Digital clock                | Shows the time (hours and minutes) (page 34).  |
| Gear position indicator      | Shows the gear position (page 35).   |
| AT/MT/LOW indicator          | Shows the transmission mode (page 36).   |
| SPORT indicator              |  |
| Drive mode indicator         | Shows the driving mode (page 37).  |
| SEL/SET switch               | This switch is used to select the mode, to change the mileage unit and adjust/ resets the digital clock, tripmeter and hour meter (page 24). |