

Sub-Transmission Oil

Oil Recommendation

The recommended sub-transmission oil is the same as the engine oil (page 138).

Checking & Adding Sub-Transmission Oil

Refer to *Safety Precautions* on page 115.

Check the sub-transmission oil level as specified in the maintenance schedule (page 119) and add, if needed.

Before driving your SXS, check the sub-transmission oil level.

1. Park your Honda SXS on a firm, level surface. Shift the shift select lever into the park (P) position.
2. Remove the oil fill cap/dipstick from the transmission cover and wipe it clean.
3. Insert the dipstick without screwing it in, then remove the oil fill cap/dipstick and check the oil level. The oil level should be between the upper level mark and the lower level mark on the oil fill cap/dipstick.