Brake Pedal Inspection

Refer to Safety Precautions on page 115.

Check that the brake pedal moves smoothly and does not feel abnormally spongy according to the maintenance schedule (page 120).

