Lubrication

Lubricate the door latch spring as shown in the following illustration. Open the door (page 40).

The left and right door latch springs can be lubricate in the same manner.

LEFT SIDE

