

# Suspension

## Front Suspension Adjustment

Using a pin spanner, which is available from your dealer, the front suspension can be adjusted for driver and passenger weight, and driving conditions by changing the spring pre-load.


Do not attempt to disassemble, service, or dispose of the damper; see your dealer. The instructions found in this owner's manual are limited to adjustments of the shock assembly only.

## Front Suspension Spring Pre-Load

Refer to *Safety Precautions* on page 91.

front

spring pre-load adjuster



The spring pre-load adjuster has 5 positions for different load or driving conditions. Before adjusting the spring pre-load, jack up your Honda SXS (page 110) to avoid damaging the adjusters.

Use the pin spanner to adjust the shock spring pre-load.

Pin spanner part number: 07702-0020001

Available through your dealer.