Brake Pedal Inspection

Refer to Safety Precautions on page 91.

Check that the brake pedal moves smoothly and does not feel abnormally spongy. Refer to the maintenance schedule on page 96.

