Removal from Storage

Refer to Safety Precautions on page 91.

- 1. Uncover and clean your Honda SXS.
- 2. If your Honda SXS has been stored for more than four months change the engine oil (page 119).
- 3. If your Honda SXS has been stored for more than two months ask your dealer to drain and replace the fuel.
- 4. Charge the battery (page 174) as required. Install the battery.
- 5. Perform a pre-ride inspection (page 58), then test-ride your Honda SXS at low speeds.