

If the Shift Paddles Do Not Function

If one or both shift paddles do not function, see the following instructions. If proper function cannot be restored, see your dealer.

1. If the engine is running, stop the SXS.
2. Turn the ignition switch to the "OFF" (O) position.
3. After the engine stops, turn the ignition switch to the "ON" (I) position.
4. Pull the upshift paddle then the downshift paddle and check that they are functioning.
5. If both paddles are functioning, shift into neutral and restart the engine.
If one or both paddles are not functioning, see *Emergency Gear Selection & Operation*, page 197.

When the battery is low:

- See *If the Battery Is Low*, page 210.