

Basic Operation


To stop the engine, turn the ignition switch to the OFF (w) position. Remember to apply the parking brake and remove the key if you plan to leave the vehicle.

Shifting Gears

Selecting a Shift Position

You can drive your vehicle either forward or backward by moving the shift select lever from neutral (N) to drive (D) or reverse (R).

Remember, to avoid damaging the transmission, move the shift select lever only when the vehicle is stopped and the engine is idling.



(SXS700M2D/M4D only)

When the shift select lever is in the drive (D) position, you can switch between AT mode and MT mode by turning the AT/MT switch. In AT mode, you can use the shift paddles to temporarily select a gear.