


# Controls & Features

## Parking Brake

### LEFT HANDLEBAR



(1) lock lever

(2) parking brake pin

(3) clutch lever/parking brake lever

(A) to lock

The lock lever (1) and parking brake pin (2) on the clutch lever/parking brake lever (3) allows it to be used as a parking brake. To operate, push down and hold the parking brake pin, squeeze the clutch lever/parking brake lever and then lock it with the lock lever. See *Parking* page 71.

To release the parking brake, squeeze the clutch lever/parking brake lever.