

Rear Final Gear Oil

5. Fill the rear final gear with the recommended oil.

4.2 US oz (125 cm³)

Make sure the oil level is at the lower edge of the oil fill inspection hole (5).

6. Coat a new O-ring with grease and install it into the fill cap groove and tighten it to the specified torque:

9 lbf·ft (12 N·m , 1.2 kgf·m)

7. Pour the drained oil into a suitable container and dispose of it in an approved manner ([page 202](#)).

NOTICE

Improper disposal of drained fluids is harmful to the environment.