

## B

bank angle sensor ignition cut-off system.....	62
battery.....	165
brake light switch adjustment.....	152
brakes,	
cables.....	151
draining water from.....	153
fluid.....	143
front brake lever.....	31
pad wear.....	146
parking.....	32
rear brake lever.....	31
rear brake lever freeplay.....	149
rear brake pedal.....	31
rear brake pedal freeplay.....	147
shoe wear.....	151
braking.....	69
break-in guidelines.....	215
button, hourmeter/odometer/tripmeter select.....	13, 17, 20, 21, 22