


Indicators & Displays

(For TRX500FPA)

To reset the indicator, press and hold both the odometer/tripmeter select button (2) and digital clock/hourmeter select button (4) for more than 2 seconds. The indicator will disappear.



(1) oil change indicator
(2) odometer/tripmeter
select button

(4) digital clock/hourmeter
select button
(TRX500FPA)

If the oil is changed before the oil change indicator appears, be sure to reset the oil change indicator after changing the oil. The indicator will appear for 2 seconds, then disappear. This means the indicator is reset.