


# Indicators & Displays

---

The indicators and displays on your ATV keep you informed, alert you to possible problems, and make your riding safer and more enjoyable. Refer to the indicators frequently. Their functions are described on the following pages.



- |  |   |
|--|---|
| (1) neutral indicator                  | (6) PS (Electric Power Steering) indicator (TRX500FE2 only) |
| (2) reverse indicator                  | (7) multi-function display                                  |
| (3) differential lock indicator        | (8) mode select button                                      |
| (4) PGM-FI indicator                   |   |
| (5) high coolant temperature indicator |   |