


Starting & Stopping the Engine

Always follow the proper starting procedure described below.

For your safety, avoid starting or operating the engine in an enclosed area such as a garage. Your ATV's exhaust contains poisonous carbon monoxide gas which can collect rapidly in an enclosed area and cause illness or death.

Preparation



- (1) ignition switch
- (2) neutral indicator
- (3) engine stop switch

1. Before starting, select a level surface and lock the parking brake ([page 38](#)).
2. Turn the ignition switch (1) ON (q).

Confirm the following:

- The transmission is in neutral, and the neutral indicator (2) is ON.
- The engine stop switch (3) is set to RUN (e).