
Also, if you hit a pothole or other hard object while riding, stop as soon as you safely can and carefully inspect the tires for damage.

## Tread Wear



- (1) groove depth
- (2) wear indicator

(3) wear indicator location mark

To check the condition of a tire tread, measure the groove depth (1) in the center of the tire, or check the wear indicator (2). For best performance, you should replace a tire before the tread depth at the center reaches the following limits:

| front | 3/16 in (4 mm) |
|-------|----------------|
| rear  | 3/16 in (4 mm) |