

Basic Operation & Riding

This section gives basic riding instructions, including how to start and stop your engine, and how to use the throttle and brakes. It also provides important information on riding with cargo.

To protect your new engine and enjoy optimum performance and service life, refer to Break-in Guidelines (page 185).

Safe Riding Precautions	45
Speed Restrictors for New Riders.....	45
Off-road Use Only.....	49
Keep Hands and Feet on Controls.....	50
Control Speed	51
Use Care on Unfamiliar or Rough Terrain	52
Do Not Perform Stunts.....	54
Ride Only When Visibility Is Good	54
Starting & Stopping the Engine.....	55
Preparation.....	55
Starting Procedure	56
Flooded Engine.....	59
How to Stop the Engine.....	59
Shifting Gears.....	60

(cont'd)