


# Starting & Stopping the Engine

---

## Preparation



1. Before starting, select a level surface and lock the parking brake (page 26).
2. Turn the fuel valve (1) and ignition switch (2) to ON (q).

Confirm the following:

- The transmission is in neutral, and the neutral indicator (3) is on.
- The engine stop switch (4) is set to RUN (e ).