

Instruments



Tachometer red zone
(excessive engine rpm range)

Tachometer

FCD button

TOTAL/TRIP button

NOTICE

Do not operate the engine in the tachometer red zone. Excessive engine speed can adversely affect engine life.

TOTAL/TRIP button & FCD button

Press and hold both buttons to change the speed, mileage and fuel mileage units ("mph" and "mile" and "mile/gal" or "km/h" and "km" and "km/L") for the speedometer, odometer, and tripmeter, also to change the temperature ("°F" or "°C").

Press **FCD** button to select either "mph" and "mile" and "mile/gal" or "km/h" and "km" and "km/L", then press **TOTAL/TRIP** button to set.

Press **FCD** button to select either "°F" or "°C", then press **TOTAL/TRIP** button to set.