


Switches *(Continued)*

VFR1200X/XA




Turn signal switch

The turn signal will automatically stop when you complete the turn. (You can manually cancel the lights by pressing the switch in.)

When used for a lane change, the turn signal will automatically stop in 7 seconds or after riding 131 yards (120 m).

In some cases, the timing at which the turn signal stops could be less or more. Always use the recommended tires to ensure correct automatic cancellation operation.

Torque Control switch

Torque Control level setting and Torque Control on/off.  **P.43**