

■ Rear Wheel

Removal

1. VFR1200X/XD

Support your motorcycle securely and raise the rear wheel off the ground using a maintenance stand or a hoist.

VFR1200XA/XDA

Support your motorcycle securely and raise the rear wheel off the ground using the center stand or a hoist.

2. Loosen the muffler band bolt.
3. Remove the muffler stay bolt, nut and washers.

