

Refueling	56	Stopping Engine	130
Removal		Storage	
Battery.....	77	Equipment	58
Clip.....	78	Owner's Manual.....	130
Right Engine Heat Guard	78	Storing Your Motorcycle	134
Right Under Cowl.....	78	Switches	32
Seat.....	80		
Repair Kit	114	T	
Reporting Safety Defects (U.S.)	150	Tachometer	20
Riding Precautions	11	Throttle	96
		Tires	
S		Air Pressure	73
S Mode	49, 51, 53	Puncture.....	114
Safety Guidelines	3	Replacing.....	73, 114
Safety Labels	8	Torque Control	15, 43
Safety Precautions	10	Torque Control Indicator	31, 111
Shifting Gears	47	Torque Control OFF Indicator	31
Side Stand	94	Torque Control Switch	34, 36
Side Stand Ignition Cut-off System	94	Transporting Your Motorcycle	135
Specifications	151	Tripmeter	130
Speedometer	21	Troubleshooting	106
Start Button	32, 37, 45, 46	Turn Signal Indicators	31
Starting the Engine	45	Turn Signal Switch	34, 36
Steering Lock	38		