4. To set the hour, push the button until the desired hour is displayed.
   • The time is advanced by one hour, each time the button is pushed.

5. Push and hold the button for more than 2 seconds. The minute display will start flashing.