

9. Install the muffler, muffler bracket bolt A, B, nuts and washers.  
Tighten the muffler bracket bolt A, B, nuts and exhaust pipe joint nuts.

**Exhaust pipe joint nuts:**

**Torque:** 17 lbf·ft (23 N·m, 2.3 kgf·m)

**Muffler bracket bolt A, B and nuts:**

**Torque:** 20 lbf·ft (27 N·m, 2.8 kgf·m)

If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.