


Instruments

Speedometer



Mode switch

Display Check

When the ignition switch is turned on, all the modes and digital segments will show. If any part of these displays does not come on when it should, have your dealer check for problems.