


Battery Cover



Removal

1. Open the seat. 2 P. 37
2. Press the tabs and remove the battery cover.

Installation

Install the parts in the reverse order of removal.