

Battery Goes Dead

Charge the battery using a motorcycle battery charger.

Remove the battery from the scooter before charging.

Do not use an automobile-type battery charger, as these can overheat a scooter battery and cause permanent damage.

If the battery does not recover after recharging, contact your dealer.

NOTICE

Jump starting using an automobile battery is not recommended, as this can damage your scooter's electrical system.

Burned-out Light Bulb

All light bulbs on the scooter are LEDs. If there is a LED which is not turned on, see your dealer for this service.