

# Refueling

**Fuel type:** Unleaded gasoline only

**Recommended fuel octane number:**  
Pump Octane Number (PON) 86 or higher.

**Tank capacity:** 2.11 US gal (8.0 L)

**Refueling and Fuel Guidelines** ➔ P.13

## Opening the Fuel Fill Cap

- 1 Insert the ignition key and turn it to the position of SEAT FUEL.
- 2 Push the FUEL side of the fuel lid and seat opener switch.
  - ▶ The fuel lid opens.

