

## Riding Precautions

### Wet or Rainy Conditions

Road surfaces are slippery when wet, and wet brakes further reduce braking efficiency. Exercise extra caution when braking in wet conditions.

If the brakes get wet, apply the brakes while riding at low speed to help them dry.

### Parking

- Park on a firm, level surface.
- If you must park on a slight incline or loose surface, park so that the scooter cannot move or fall over.
- Make sure that high-temperature parts cannot come into contact with flammable materials.
- Do not touch the engine, muffler, brakes and other high-temperature parts until they cool down.

- To reduce the likelihood of theft, always lock the handlebar, lock the ignition switch (➡ P. 33) and leave your scooter while taking the Honda SMART Key with you. Deactivate the Honda SMART Key system if necessary.

➡ P. 28

Use of an anti-theft device is also recommended.

Also set the anti-theft alarm system.

### Parking with the Side Stand or Centre Stand

1. Stop the engine.

2. **Using the side stand**

Push the side stand down.

Slowly lean the scooter to the left until its weight rests on the side stand.

2. **Using the centre stand**

To lower the centre stand, stand on the left side of the scooter.

Hold the left handle grip and the grab rail.

Press down on the tip of the centre stand with your right foot and, simultaneously, pull up and back.