


## Changing the Answer Back Buzzer Sound Pattern


You can select 3 buzzer sound patterns.

- 1 Make sure that the Honda SMART Key system is activated. ➔ P.28
- 2 Remove the battery cover. ➔ P.77
- 3 Push the ignition switch to authenticate the Honda SMART Key system. ➔ P.32
- 4 Connect the EM mode coupler provided in the tool kit to the EM mode connector. ➔ P.111
  - ▶ The Honda SMART Key indicator and ignition switch ring go off.

Answer back button



Ignition switch



Ignition switch ring

- 5 Push the ignition switch 1 time.
- 6 Repeat this step 3 times as follows: Press the answer back button on the Honda SMART Key 3 times and the ignition switch 1 time.
  - ▶ When the answer back button is pressed, the LED on the Honda SMART Key comes on. Make sure the LED went off before the next button pressing.
  - ▶ If the answer back button or ignition switch is not pressed for 1 minute, the Honda SMART Key indicator starts blinking and this mode will be cancelled. If so, remove the EM mode coupler, return to 3 and follow the procedure again.