

## Inspecting the Front Brake Pads

Check the condition of the brake pad wear indicators.

The pads need to be replaced if a brake pad is:

**PCX150** worn to the bottom of the indicator.

**PCX150A** worn to the indicator.

1. **PCX150** Inspect the brake pads from in front of the brake caliper.

**PCX150A** Inspect the brake pads from front lower side of the brake caliper.

If necessary have the pads replaced by your dealer.

Always replace both left and right brake pads at the same time.

