





Maintenance Schedule

Items	Pre-ride Check ➤ P. 41	Odometer Reading*1									Annual Check	Regular Replace	Refer to page
		x 1,000 km	1	4	8	12	16	20	24				
		x 1,000 mi	0.6	2.5	5	7.5	10	12.5	15				
Side Stand (XR150LEK-NZ type Only)	I			I	I	I	I	I	I	I	I		70
Side Stand (Except XR150LEK-NZ type)				I	I	I	I	I	I	I	I		70, 71
Suspension				I	I	I	I	I	I	I	I		-
Nuts, Bolts, Fasteners*4			I		I		I		I		I		-
Wheels/Tyres*4		I	I	I	I	I	I	I	I	I	I		48
Steering Head Bearings			I			I			I		I		-