

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to Page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
DRIVE CHAIN		NOTE (4)	EVERY 1,000 km (600 mi) I, L								78
DRIVE CHAIN SLIDER				I	I	I	I	I	I	84	
BRAKE FLUID		NOTE (5)		I	I	R	I	I	R	18, 19	
BRAKE PADS WEAR				I	I	I	I	I	I	91	
BRAKE SYSTEM			I		I		I		I	18–19, 91	
* BRAKELIGHT SWITCH					I		I		I	97	
* HEADLIGHT AIM					I		I		I	41	
CLUTCH SYSTEM			I	I	I	I	I	I	I	20	
SIDE STAND					I		I		I	86	
* SUSPENSION					I		I		I	85	
* NUTS, BOLTS, FASTENERS		NOTE (4)	I		I		I		I	—	
** WHEELS/TYRES		NOTE (4)	I	I	I	I	I	I	I	—	
** STEERING HEAD BEARINGS			I		I		I		I	—	