








Items		Frequency	Odometer Reading *1							Refer to page	
			× 1,000 mi	0.6	4	8	12	16	20		24
			× 1,000 km	1.0	6.4	12.8	19.2	25.6	32.0		38.4
Non-Emission-Related Items	Drive Chain *4		Every 500 mi (800 km): <b>I</b> <b>L</b>							65	
	Drive Chain Slider			<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	68	
	Brake Fluid *5			<b>I</b>	<b>I</b>	<b>R</b>	<b>I</b>	<b>I</b>	<b>R</b>	62	
	Brake Pads Wear			<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	63	
	Brake System		<b>I</b>		<b>I</b>		<b>I</b>		<b>I</b>	62	
	Brake Light Switch					<b>I</b>		<b>I</b>		<b>I</b>	79
	Headlight Aim					<b>I</b>		<b>I</b>		<b>I</b>	79
	Clutch System		<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	71	
	Side Stand		<b>I</b>		<b>I</b>		<b>I</b>		<b>I</b>	64	
	Suspension					<b>I</b>		<b>I</b>		<b>I</b>	–
	Spark Arrester/Muffler				<b>C</b>	<b>C</b>	<b>C</b>	<b>C</b>	<b>C</b>	<b>C</b>	61
	Nuts, Bolts, Fasteners			<b>I</b>		<b>I</b>		<b>I</b>		<b>I</b>	–
	Wheels/Tires *4			<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	44
Steering Head Bearings *4			<b>I</b>		<b>I</b>		<b>I</b>		<b>I</b>	–	

**Notes:**

- \*1: At higher odometer readings, repeat at the frequency interval established here.
- \*2: Service more frequently when riding in unusually wet or dusty areas.

\*3: 50-state type only.

\*4: Service more frequently when riding OFF-ROAD.

\*5: Replace every 2 years, or at indicated odometer intervals, whichever comes first. Replacement requires mechanical skill.