








Items		Frequency	Odometer Reading*1							Refer to page	
			× 1,000 mi	0.6	4	8	12	16	20		24
			× 1,000 km	1.0	6.4	12.8	19.2	25.6	32.0		38.4
Non-Emission-Related Items	Drive Chain*4		Every 500 mi (800 km) <b>I</b> <b>L</b>							65	
	Drive Chain Slider			<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	68	
	Brake Fluid*5			<b>I</b>	<b>I</b>	<b>R</b>	<b>I</b>	<b>I</b>	<b>R</b>	62	
	Brake Pads Wear			<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	63	
	Brake System		<b>I</b>		<b>I</b>		<b>I</b>		<b>I</b>	62	
	Brake Light Switch				<b>I</b>		<b>I</b>		<b>I</b>	79	
	Headlight Aim				<b>I</b>		<b>I</b>		<b>I</b>	79	
	Clutch System		<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	71	
	Side Stand		<b>I</b>		<b>I</b>		<b>I</b>		<b>I</b>	64	
	Suspension				<b>I</b>		<b>I</b>		<b>I</b>	-	
	Spark Arrester/Muffler				<b>C</b>	<b>C</b>	<b>C</b>	<b>C</b>	<b>C</b>	<b>C</b>	61
	Nuts, Bolts, Fasteners			<b>I</b>		<b>I</b>		<b>I</b>		<b>I</b>	-
	Wheels/Tires*4			<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	<b>I</b>	44, 70
Steering Head Bearings*4			<b>I</b>		<b>I</b>		<b>I</b>		<b>I</b>	-	

### Notes:

- \*1 : At higher odometer readings, repeat at the frequency interval established here.
- \*2 : Service more frequently when riding in unusually wet or dusty areas.
- \*3 : 50-state models (meets California).

\*4 : Service more frequently when riding OFF-ROAD.

\*5 : Replace every 2 years, or at indicated odometer interval, whichever comes first. Replacement requires mechanical skill.