

# Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

An optional larger tool kit may be available.

Check with your Honda dealer's parts department.

<b>Importance of Maintenance</b> .....	P. 31	<b>Brakes</b> .....	P. 64
<b>Maintenance Schedule</b> .....	P. 33	<b>Side Stand</b> .....	P. 67
<b>Maintenance Fundamentals</b> .....	P. 36	<b>Drive Chain</b> .....	P. 68
<b>Removing &amp; Installing Body Components</b> ..	P. 49	<b>Wheels</b> .....	P. 73
Battery .....	P. 49	<b>Clutch</b> .....	P. 74
Seat .....	P. 50	<b>Throttle</b> .....	P. 77
Shroud.....	P. 51	<b>Other Adjustments</b> .....	P. 78
Left Side Cover .....	P. 52	Adjusting the Headlight Aim .....	P. 78
Right Side Cover .....	P. 53	Adjusting the Front Suspension.....	P. 79
<b>Spark Plug</b> .....	P. 54	Adjusting the Rear Suspension .....	P. 81
<b>Spark Arrester/Muffler</b> .....	P. 56		
<b>Engine Oil</b> .....	P. 57		
<b>Engine Idle Speed</b> .....	P. 62		
<b>Air Cleaner</b> .....	P. 63		